



PUMP STANDOFF INSTRUCTIONS

- Choose drum seal which is closest fit to your
- standoff.
- Put Teflon tape around standoff threads prior to installation to prevent air leaks.
- Add siphon tubes to get to bottom of container if necessary (included with kit)



Westcott
Distribution



184 West Tenth Street, New York, 10014
Voice (646) 486 3636 Fax (212) 243 6070

2/4/05