



## BUTTRESS ADAPTER INSTRUCTIONS

- Put Teflon tape around buttress threads prior to installation to prevent air leaks.
- Install with washer



Westcott  
Distribution



184 West Tenth Street, New York, 10014  
Voice (646) 486 3636 Fax (212) 243 6070

1/25/05