



REMOTE TAP SET-UP OPTIONS

SET UP VERSION # 1

- Attach the hose of remote tap to existing tap with provided worm clamp



SET UP VERSION # 2

- Attach the hose of remote tap directly to pump – see attached instructions

