


GoatThroat with Kalrez and Teflon



Parts List

Main Piston

Check Valve

Pressure release - turn to open

Siphon Tube connection

If using pneumatic adapter/regulator, remove plug here and install regulator at this point



INSTALLATION INSTRUCTIONS

1. Wrap bottom of pump with several wraps of provided teflon tape.
2. Set up siphon tube:
 - a. Measure and write down the overall length of drum.
 - b. Assemble tubes and connectors per page 9 of instruction manual - steps 1 and 2.
 - c. Cut to 7.25-inch less than the height of the drum.
 - d. Assemble to siphon tube connection on pump.
 - e. Insert pump and tubes into 2-inch pipe threaded side of drum, and screw into bung hole 5 - 6 turns, with the final position of the pump facing forward.

OPERATING INSTRUCTIONS

- 1, Follow instructions on page 11 of the instruction manual.
2. To release pressure after use, open the pressure release valve by turning counter-clockwise.